

## AERO COMMANDER

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>500, 500A, 500B, 500U, 560A, 560E, 560F, 680, 680E, 680F 680F(P), 720</b>	ALL MODELS	CENTER	630062-511, -507	
		LH INBOARD FORWARD	630060-511, -501	
		RH INBOARD FORWARD	630060-512, -502	
		LH INBOARD AFT	630061-511, -501	
		RH INBOARD AFT	630061-512, -502	
		LH OUTBOARD FORWARD	630063-511, -501	
		RH OUTBOARD FORWARD	630063-512, -502	
		LH OUTBOARD AFT	630064-515, -501	
		RH OUTBOARD AFT	630064-516, -502	
		LH OIL	630066-1	
RH OIL	630066-2			
<b>680T, 680V, 680W, 681</b>	ALL MODELS  EXCEPT 681 EXCEPT 681 681 ONLY 681 ONLY OPTIONAL OPTIONAL OPTIONAL OPTIONAL OPTIONAL OPTIONAL OPTIONAL OPTIONAL OPTIONAL	UPPER CENTER	630062-511, -507	
		LOWER CENTER	630204-503, -501	
		LH INBOARD FORWARD	630060-511, -501	
		RH INBOARD FORWARD	630060-512, -502	
		LH INBOARD AFT	630061-511, -501	
		RH INBOARD AFT	630061-512, -502	
		LH OUTBOARD FORWARD	630063-511, -501	
		RH OUTBOARD FORWARD	630063-512, -502	
		LH OUTBOARD AFT	630064-515, -501	
		RH OUTBOARD AFT	630064-516, -502	
		LH OUTBOARD AFT	630064-511, -507	
		RH OUTBOARD AFT	630064-512, -508	
		LH INBOARD FORWARD	630304-505, -501	
		RH INBOARD FORWARD	630304-506, -502	
		LH INBOARD AFT	630301-505, -501	
		RH INBOARD AFT	630301-506, -502	
		LH OUTBOARD FORWARD	630296-505, -501	
		RH OUTBOARD FORWARD	630296-506, -502	
LH OUTBOARD AFT	630302-505, -501			
RH OUTBOARD AFT	630302-506, -502			

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>690, 690A 690B</b>	ALL MODELS *AUX TANKS OPTIONAL FOR 690	UPPER CENTER	630062-511, 507	
		LOWER CENTER	630204-503, -501	
		LH SMALL INBOARD FORWARD	630308-501,-1	
		RH SMALL INBOARD FORWARD	630308-502, -2	
		LH SMALL INBOARD AFT	630307-501, -1	
		RH SMALL INBOARD AFT	630307-502, -2	
		LH LARGE INBOARD FORWARD	630060-509, -507	
		RH LARGE INBOARD FORWARD	630060-510, -508	
		LH OUTBOARD FORWARD	630063-509, -507	
		RH OUTBOARD FORWARD	630063-510, -508	
		LH OUTBOARD AFT	630064-513, -509	
		RH OUTBOARD AFT	630064-514, -510	
		LH FORWARD INBOARD AUX	630304-503, -1	
		RH FORWARD INBOARD AUX	630304-504, -2	
		LH AFT INBOARD AUX	630296-503, -1	
		RH AFT INBOARD AUX	630296-504, -2	
		LH FORWARD OUTBOARD AUX	630301-503, -1	
		RH FORWARD OUTBOARD AUX	630301-504, -2	
		LH AFT OUTBOARD AUX	630302-503, -1	
		RH AFT OUTBOARD AUX	630302-504, -2	
<b>690C, 690D, 695, 695A, 695B</b>	ALL	LH SMALL FORWARD INBOARD	630397-503, -1	
		RH SMALL FORWARD INBOARD	630397-504, -2	
	EXCEPT 695B	LH LARGE FORWARD INBOARD	630355-503, -1	
	EXCEPT 695B	RH LARGE FORWARD INBOARD	630355-504, -2	
	695B ONLY	LH LARGE FORWARD INBOARD	630355-505, -501	
	695B ONLY	RH LARGE FORWARD INBOARD	630355-506, -502	
	ALL	LH SMALL AFT INBOARD	630393-503, -501	
		RH SMALL AFT INBOARD	630393-504, -502	
	EXCEPT 695B	LH LARGE AFT INBOARD	630353-503, -1	
	EXCEPT 695B	RH LARGE AFT INBOARD	630353-504, -2	
	695B ONLY	LH LARGE AFT INBOARD	630353-505, -501	
	695B ONLY	RH LARGE AFT INBOARD	630353-506, -502	
		LH NACELLE	630356-501, -1	
		RH NACELLE	630356-502, -2	
		INBOARD CENTER WING	630354-503, -1	
		INBOARD CENTER WING	630354-505	

**AERONCA**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>15AC</b>	ALL MODELS	LH RH	2F1-6-11445LH 2F1-6-11445	

**AEROSPATIALE**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>360C DOLPHIN</b>	ALL MODELS	LH LATERAL RH LATERAL LH CENTRAL RH CENTRAL	360A55-0014-00 360A55-0015-00 360A55-0012-00 360A55-0013-00	
<b>365C DAUPHIN</b>	ALL MODELS	LH LATERAL RH LATERAL MAIN CENTER	360A55-0014-00 360A55-0015-00 360A55-0020-00	
<b>365N DAUPHIN 2</b>	ALL MODELS	LH FRONT RH FRONT LH CENTER RH CENTER REAR	365A55-3020-00 365A55-3021-00 365A55-3022-00 365A55-3023-00 365A55-3024-00	
<b>366 DAUPHIN</b>	ALL MODELS	LH FORWARD RH FORWARD LH CENTER RH CENTER AFT	366A55-1001-03 366A55-1002-03 366A55-1003-03 366A55-1004-03 366A55-1005-03	
<b>341G GAZELLE</b>	ALL MODELS	LH SELF SEALING	341A55-1065-26 341A55-1065-27	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>332L, 332C SUPER PUMA</b>	ALL MODELS	LONGITUDINAL	332A55-0101-02	
		LONGITUDINAL	332A55-0102-02	
		LONGITUDINAL	332A55-0106-00	
		LONGITUDINAL	332A55-0107-00	
	332C ONLY 332C ONLY	REAR	332A55-0103-02	
		REAR	332A55-0108-00	
		FIFTH TANK	332A55-0104-02	
		FIFTH TANK	332A55-0109-00	

<b>330, 330J PUMA</b>	ALL	LONGITUDINAL LH	330A55-1018-62	
		LONGITUDINAL LH	330A55-1018-61	
		LONGITUDINAL LH	330A55-1018-64	
		LONGITUDINAL RH	330A55-1018-63	
		LONGITUDINAL RH	330A55-1018-65	
		FRONT TANK	330A55-1016-2	
		REAR TANK	330A55-1017-02	
		FIFTH TANK	330A55-0504-22	

## **AEROSTAR**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>600, 601, 601P 602P, 700P</b>	ALL MODELS	MAIN FUEL CELL	980050-501	FCE-53583,

## **ASTRAJET, JET COMMANDER, WESTWIND**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>ALL</b>	1121	LH WING	5653042-509, -501, -503	
	1121	RH WING	5653042-510, -502, -504	
	1121	LH FUSELAGE	5653043-505, -501	
	1121	RH FUSELAGE	5653043-506, -502	
	1121 A & B	LH FUSELAGE	5653043-513	
	1121 A & B	RH FUSELAGE	5653043-514	
	<b>ALL</b>	1123,1124	LH FUSELAGE	5653043-509
1123,1124		RH FUSELAGE	5653043-510	
ALL		LH OVERWING	5653088-503, -501	
ALL		RH OVERWING	5653088-504, -502	
1125		CENTER	25W345200-503	

**BEECHCRAFT**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>D18S, E18S G18S, H18S</b>	A40-1015	NOSE 77 GALLON	404-189612	
	BA1-460	NOSE 77 GALLON	414-189621-1	
	BA1-671	LH OUTBOARD 60 GALLON	414-920010-9,(7, 5)	
	BA1-671	RH OUTBOARD 60 GALLON	414-920010-10, (8, 6)	
	BA632-671	LH CENTER SECTION	18-920012-7	
	BA632-671	RH CENTER SECTION	18-920012-8	
<b>33 DEBONAIR</b>	CD1-387	LH MAIN 25 GALLON	95-380027-1,	50-920008-7
	CD1-387	RH MAIN 25 GALLON	95-380027-2,	50-920008-8
	CD1-387	LH MAIN 25 GALLON (BAFFLED)	96-380046-9	35-9009-3S,
	CD1-387	RH MAIN 25 GALLON (BAFFLED)	96-380046-10	35-9009-4S,
	CD1-387	RH AUX 10 GALLON	35-921222-6, (-8)	
	CD388-UP	LH MAIN 40 GALLON	35-921242-11	
	CD388-UP	RH MAIN 40 GALLON	35-921242-12	
	CD388-UP	LH MAIN 40 GALLON (BAFFLED)	35-380135-11 (-9)	35-9009-1S,
	CD388-UP	RH MAIN 40 GALLON (BAFFLED)	35-380135-12 (-10)	35-9009-2S,
	<b>35, 36 BONANZA</b>	D1-3538	LH MAIN 20 GALLON, W SNAPS	35-921540
D1-3538		RH MAIN 20 GALLON, W SNAPS	35-921540-1	
D3539-5725		LH MAIN 20 GALLON	35-921218-5	
D3539-5725		RH MAIN 20 GALLON	35-921218-10	
D5726-UP, 36		LH MAIN 25 GALLON	95-380027-1,	50-920008-7
D5726-UP, 36		RH MAIN 25 GALLON	95-380027-2,	50-920008-8
D5726-UP, 36		LH MAIN 25 GALLON (BAFFLED)	96-380046-9	35-9009-3S,
D5726-UP, 36		RH MAIN 25 GALLON (BAFFLED)	96-380046-10	35-9009-4S,
D6562-UP, 36		LH MAIN 40 GALLON	35-921242-11, (-5)	
D6562-UP, 36		RH MAIN 40 GALLON	35-921242-12, (-6)	
D6562-UP, 36		LH MAIN 40 GALLON (BAFFLED)	35-380135-11 (9)	35-9009-1S,
D6562-UP, 36		RH MAIN 40 GALLON (BAFFLED)	35-380135-12 (10)	35-9009-2S,
D399-7017		LH AUX 10 GALLON	35-921222-5, (-7)	
D399-7017		RH AUX 10 GALLON	35-921222-6, (-8)	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>50 TWIN BONANZA</b>	H1-CH151	LH MAIN 25 GALLON	95-380027-1,	50-920008-7
	H1-CH151	RH MAIN 25 GALLON	95-380027-2,	50-920008-8
	H1-CH151	LH LE MAIN GALLON (BAFFLED)	35-380135-11 (9)	35-9009-3S,
	H1-CH151	RH LE MAIN GALLON (BAFFLED)	35-380135-12 (10)	35-9009-4S,
	CH152-UP	LH MAIN	50-921507-11, (-9)	
	CH152-UP	RH MAIN	50-921507-12, (-10)	
	CH152-DH143	LH AFT INBOARD	50-921506-1	
	CH152-DH143	RH AFT INBOARD	50-921506-2	
	DH144-UP	LH AFT INBOARD	50-921510-13, (-1,-5,-9)	
	DH144-UP	RH AFT INBOARD	50-921510-14, (-2,-6,-10)	
	EH1-UP	LH AFT OUTBOARD	50-921510-17, (-3,-7,-11)	
	EH1-UP	RH AFT OUTBOARD	50-921510-16, (-4,-8,-12)	
	ALL	LH CENTER SECTION	50-920010-6, (-2)	
	ALL	RH CENTER SECTION	50-920010-7, (-4)	
	<b>55A, 55B, 55C, 55D 55E BARON 95, B95, D95A, E95 TRAVEL AIR</b>	TC1-1607	LH MAIN 25 GALLON	95-380027-1
TE1-942		RH MAIN 25 GALLON	95-380027-2	50-920008-8
TD2-UP		LH MAIN 25 GALLON (BAFFLED)	96-380046-9	35-9009-3S,
		RH MAIN 25 GALLON (BAFFLED)	96-380046-10	35-9009-4S,
		LH MAIN 40 GALLON	35-921242-11, (-5)	
		RH MAIN 40 GALLON	35-921242-12, (-6)	
		LH MAIN 40 GALLON (BAFFLED)	35-380135-11 (9)	35-9009-1S,
		RH MAIN 40 GALLON (BAFFLED)	35-380135-12 (10)	35-9009-2S,
		LH AUX 17 GALLON	95-380015-3	
		RH AUX 17 GALLON	95-380015-4	
		LH AUX 31 GALLON	95-920011-13, (-1, -7, -9)	
		RH AUX 31 GALLON	95-920011-14, (-2, -8, -10)	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>		
<b>55A, 55B, 55C, 55D 55E, 58, BARON</b>  <i>(CONFIRM GALLON CAPACITY OF FUEL SYSTEM FOR ACCURATE PART NUMBER FOR A/C CONFIGURATION)</i>	142 GAL, TH1-384	LH MAIN 40 GALLON (BAFFLED)	58-380030-9, (-7)	60-9002-1S		
		RH MAIN 40 GALLON (BAFFLED)	58-380030-10, (-8)			
		LH AUX 31 GALLON	58-380003-11, -3, -7	60-9002-2S,		
		RH AUX 31 GALLON	58-380003-12, -4, -8			
		172 GAL, TH1-384	LH MAIN 40 GALLON (BAFFLED)		58-380030-9, (-7)	60-9002-1S
			RH MAIN 40 GALLON (BAFFLED)		58-380030-10, (-8)	60-9002-2S
	LH AUX 31 GALLON		58-380003-9, -1, -5			
	RH AUX 31 GALLON		58-380003-10, -2, -6			
		106 GALLON SYS <i>TC-1608-2002, TE943-1083, TH385-772</i>	LH MAIN 40 GALLON	002-920033-1, (-3)		
			RH MAIN 40 GALLON	002-920033-2, (-4)		
			LH LE OUTBOARD	002-920013-3, (-1)		
			RH LE OUTBOARD	002-920013-4, (-2)		
		142 GALLON SYS	LH MAIN 40 GALLON	002-920033-1, (-3)		
			RH MAIN 40 GALLON	002-920033-2, (-4)		
LH AUX 31 GALLON			58-380003-11, -3, -7			
RH AUX 31 GALLON			58-380003-12, -4, -8			
172 GALLON SYS		LH MAIN 40 GALLON	002-920033-1, (-3)			
		RH MAIN 40 GALLON	002-920033-2, (-4)			
		LH LE OUTBOARD	002-920013-3, (-1)			
		RH LE OUTBOARD	002-920013-4, (-2)			
		LH AUX 31 GALLON	58-380003-9, -1, -5			
		RH AUX 31 GALLON	58-380003-10, -2, -6			
	106 GALLON SYS <i>TC2003-UP, TE1084-UP, TH773-1458</i>	LH MAIN 40 GALLON (BAFFLED)	002-920034-3, (-1)			
		RH MAIN 40 GALLON (BAFFLED)	002-920034-4, (-2)			
		LH LE OUTBOARD	002-920013-3, (-1)			
		RH LE OUTBOARD	002-920013-4, (-2)			
	142 GALLON SYS	LH MAIN 40 GALLON (BAFFLED)	002-920034-3, (-1)			
		RH MAIN 40 GALLON (BAFFLED)	002-920034-4, (-2)			
		LH AUX 31 GALLON	58-380003-11, -3, -7			
		RH AUX 31 GALLON	58-380003-12, -4, -8			
	172 GALLON SYS	LH MAIN 40 GALLON (BAFFLED)	002-920034-3, -1			
		RH MAIN 40 GALLON (BAFFLED)	002-920034-4, -2			
		LH LE OUTBOARD	002-920013-3, -1 INT. NIPPLE			
		RH LE OUTBOARD	002-920013-4, -2 INT. NIPPLE			
	200 GALLON SYS	LH AUX 31 GALLON	58-380003-9, -1, -5			
		RH AUX 31 GALLON	58-380003-10, -2, -6			
SAME AS 172 EXCEPT LE		OTBD TANKS				
LH LE OUTBOARD		60-92046-3, -1				
	RH LE OUTBOARD	60-921046-4, -2				

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>56TC, A56TC BARON</b>	TG1-68	LH MAIN	60-389001-1	
	TG1-68	RH MAIN	60-389001-2	
	TG1-68	LH BOX SECTION	60-389002-3, -1	
	TG1-68	RH BOX SECTION	60-389002-4, -2	
	TG1-68	LH NACELLE	60-389003-3, -1	
	TG1-68	RH NACELLE	60-389003-4, -2	
	TG69-UP	LH MAIN	60-389020-1	
	TG69-UP	RH MAIN	60-389020-2	
	TG69-UP	LH LE OUTBOARD	60-389021-1 EXT. NIPPLE	
	TG69-UP	RH LE OUTBOARD	60-389021-2 EXT. NIPPLE	
	TG69-UP	LH BOX SECTION	60-389022-3, -1	
	TG69-UP	RH BOX SECTION	60-389022-4, -2	
	TG69-UP	LH NACELLE	60-389023-7, -5	
	TG69-UP	RH NACELLE	60-389023-8, -6	
	<b>60, A60 DUKE</b>	P1-246	LH MAIN	60-389020-1
P1-246		RH MAIN	60-389020-2	
P1-246		LH LE OUTBOARD	60-389021-1	
P1-246		RH LE OUTBOARD	60-389021-2	
P1-246		LH BOX SECTION	60-389022-3, -1	
P1-246		RH BOX SECTION	60-389022-4, -2	
P1-246		LH NACELLE	60-389023-7, -5	
P1-246		RH NACELLE	60-389023-8, -6	
<b>B60 DUKE</b>	P247-364	LH MAIN	58-380030-9, -7	60-9002-1S
	P247-364	RH MAIN	58-380030-10, -8	60-9002-2S
	P247-265	LH LE OUTBOARD	60-389021-1	
	P247-265	RH LE OUTBOARD	60-389021-2	
	P266-UP	LH LE OUTBOARD	002-920013-3, -1	
	P266-UP	RH LE OUTBOARD	002-920013-4, -2	
	P247-364	LH BOX SECTION	60-389022-3, -1	
	P247-364	RH BOX SECTION	60-389022-4, -2	
	P247-364	LH NACELLE	60-389023-7, -5	
	P247-364	RH NACELLE	60-389023-8, -6	
	P365-401	LH MAIN	58-380030-9, -7	60-9002-1S
	P365-401	RH MAIN	58-380030-10, -8	60-9002-2S
	P401-UP	LH MAIN	60-921057-3,-1	
	P401-UP	RH MAIN	60-921057-4, -2	
	P365-UP	LH LE OUTBOARD	60-921046-3, -1	
	P365-UP	RH LE OUTBOARD	60-921046-4, -2	
	P365-UP	LH BOX SECTION	60-389022-3, -1	
	P365-UP	RH BOX SECTION	60-389022-4, -2	
	P365-UP	LH NACELLE	60-389023-7, -5	
	P365-UP	RH NACELLE	60-389023-8, -6	



<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>65, A65, 80, A80, B80 QUEENAIR</b>	LC1-229, LD1-150	LH MAIN 25 GALLON	50-921507-11, -9	
	LC1-229, LD1-150	RH MAIN 25 GALLON	50-921507-12, -10	
	LC1-229, LD1-279	LH AUX INBOARD	50-921510-13, (-1, -5, -9)	
	LC1-229, LD1-279	RH AUX INBOARD	50-921510-14, (-2, -6, -10)	
	LC1-229, LD1-150	LH AUX OUTBOARD	50-921510-17, (-3, -7, -11)	
	LC1-229, LD1-150	RH AUX OUTBOARD	50-921510-16, (-4, -8, -12)	
	LC1-229, LD1-279	LH CENTER SECTION	50-920010-6	
	LC1-229, LD1-279	RH CENTER SECTION	50-920010-7	
	LC230-UP, LD151-UP	LH MAIN 40 GALLON	50-921552-11, -1, -3, -5, -7, -9	
	LC230-UP, LD151-UP	RH MAIN 40 GALLON	50-921552-12, -2, -4, -6, -8, -10	
	LC230-UP, LD280-UP	LH AUX INBOARD	50-389034-11, -1, -7	
	LC230-UP, LD280-UP	RH AUX INBOARD	50-389034-12, -2, -8	
	LC230-UP, LD151-UP	LH AUX OUTBOARD	50-921554-11, -1, -7	
	LC230-UP, LD151-UP	RH AUX OUTBOARD	50-921554-12, -2, -8	
	LC230-UP, LD280-UP	LH CENTER SECTION	50-389035-11	50-920101-109
	LC230-UP, LD280-UP	RH CENTER SECTION	50-389035-12	50-920101-110
	<b>90, A90, B90, C90, C90A, E90, F90, KING AIR</b>	LJ1-UP	LH MAIN 40 GALLON	50-921552-11, -1, -3, -5, -7, -9
LJ1-UP		RH MAIN 40 GALLON	50-921552-12, -2, -4, -6, -8, -10	
LW1-UP		LH MAIN 40 GALLON	100-381000-5, -1, -3	
LW1-UP		RH MAIN 40 GALLON	100-381000-6, -2, -4	
LA226-UP		LH MAIN 40 GALLON	100-381000-13	
LA226-UP		RH MAIN 40 GALLON	100-381000-14	
ALL		LH INBOARD AFT	50-389034-11, -1, -7	
ALL		RH INBOARD AFT	50-389034-12, -2, -8	
LJ1-UP		LH OUTBOARD AFT	50-921554-11, -1, -7	
LJ1-UP		RH OUTBOARD AFT	50-921554-12, -2, -8	
LW1-UP		LH OUTBOARD AFT	100-381001-9, -1, -3, -5, -7	
LW1-UP		RH OUTBOARD AFT	100-381001-10, -2, -4, -6, -8	
LJ1-UP		LH CENTER SECTION	50-389035-11	50-920101-109
LJ1-UP		RH CENTER SECTION	50-389035-12	50-920101-110
LW1-UP		LH CENTER SECTION	100-381002-5, -1	
LW1-UP		RH CENTER SECTION	100-381002-6, -2	
LW1-UP		LH LE OUTBOARD	60-389021-7, -1 EXT. NIPPLE	
LW1-UP		RH LE OUTBOARD	60-389021-8, -2 EXT. NIPPLE	
LA2-UP		LH LE OUTBOARD	002-920013-3, -1 INT. NIPPLE	
LA2-UP		RH LE OUTBOARD	002-920013-4, -2 INT. NIPPLE	
LJ1-UP		LH NACELLE	50-389029-7, -5	
LJ1-UP		RH NACELLE	50-389029-8, -6	
LW1-UP		LH NACELLE	90-920020-3, -1	
LW1-UP		RH NACELLE	90-920020-4, -2	
LA2-UP		LH NACELLE	99-380000-21	
LA2-UP		RH NACELLE	99-380000-7	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>99</b>	ALL	LH MAIN 40 GALLON	50-921552-11, -1, -3, -5, -7, -9	
		RH MAIN 40 GALLON	50-921552-12, -2, -4, -6, -8, -10	
		LH INBOARD AFT	50-389034-11, -1, -7	
		RH INBOARD AFT	50-389034-12, -2, -8	
		LH OUTBOARD AFT	50-921554-11, -1, -7	
		RH OUTBOARD AFT	50-921554-12, -1, -7	
		LH CENTER SECTION	50-389035-11	50-920101-109
		RH CENTER SECTION	50-389035-12	50-920101-110
		LH NACELLE	99-380000-5	
		RH NACELLE	99-380000-7	
		<b>100, A100, B100 KING AIR</b>	B1-89	LH MAIN 40 GALLON
B1-89	RH MAIN 40 GALLON		50-921552-12, -2, -4, -6, -8, -10	
B90-UP	LH MAIN 40 GALLON		100-381000-5, -1, -3	
B90-UP	RH MAIN 40 GALLON		100-381000-6, -2, -4	
BE1-UP	LH MAIN 40 GALLON		100-381000-7, -9, -11	
BE1-UP	RH MAIN 40 GALLON		100-381000-8, -10, -12	
B90-UP	LH LE OUTBOARD		002-920013-3, -1	
B90-UP	RH LE OUTBOARD		002-920013-4, -2	
ALL	LH INBOARD AFT		50-389034-11, -1, -7	
ALL	RH INBOARD AFT		50-389034-12, -2, -8	
B1-89	LH OUTBOARD AFT		50-921554-11, -1, -7	
B1-89	RH OUTBOARD AFT		50-921554-12, -2, -8	
B90-UP	LH OUTBOARD AFT		100-381001-9, -1, -3, -5, -7	
B90-UP	RH OUTBOARD AFT		100-381001-10, -2, -4, -6, -8	
B1-89	LH CENTER SECTION		50-389035-11	50-920101-109
B1-89	RH CENTER SECTION		50-389035-12	50-920101-110
B90-UP	LH CENTER SECTION		100-381002-5, -1	
B90-UP	RH CENTER SECTION		100-381002-6, -2	
ALL	LH NACELLE		99-380000-5	
ALL	RH NACELLE		99-380000-7	
<b>200, 200T, 200C 200CT, B200 SUPER KING AIR</b>	ALL		LH 40 GALLON LE INBOARD	101-381002-5
		RH 40 GALLON LE INBOARD	101-381002-6	
		LH LE OUTBOARD	002-920013-3, -1	
		RH LE OUTBOARD	002-920013-4, -2	
		LH INBOARD AFT	50-389034-11, -1, -7	
		RH INBOARD AFT	50-389034-12, -2, -8	
		LH OUTBOARD AFT	100-381001-9, -1, -3, -5, -7	
		RH OUTBOARD AFT	100-381001-10, -2, -4, -6, -8	
		LH NACELLE	99-380000-21	
		RH NACELLE	99-380000-7	
		LH INBOARD AUX (BOX)	50-389034-19	
		RH INBOARD AUX (BOX)	50-389034-20	
		LH CENTER SECTION	101-381001-3	
		RH CENTER SECTION	101-381001-4	
		LH MAIN	101-381001-7	
		RH MAIN	101-381001-8	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>1900</b>	ALL	LH MAIN RH MAIN LH LE OUTBOARD RH LE OUTBOARD LH AUX INBOARD RH AUX INBOARD LH AUX OUTBOARD RH AUX OUTBOARD	114-389022-1 114-389022-2 114-389038-3 114-389038-4 114-389023-1 114-389023-2 114-389024-1 114-389024-2	

**BELL**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>204</b>	ALL	LH RH	204-062-611-3 204-062-611-5	
<b>205</b>	ALL	LH REAR RH REAR CENTER LH FLOOR RH FLOOR UPPER CENTER RH FORWARD LH FORWARD RH UPPER LH UPPER	205-060-605-1 205-060-605-3 205-060-605-5 205-061-632-1 205-061-632-2 205-062-635-13 205-062-635-2 205-062-635-1 205-062-635-11 205-062-635-9	
<b>206A, 206B, AND 206BIII</b>	TO S/N 2566 S/N 3567-UP	MAIN MAIN	206-061-675-1 206-061-661-101	206-061-675-001
<b>206L</b>	ALL 3567-UP	MAIN AUX AUX	206-062-670-3 206-062-632-1 206-062-632-3	206-062-670-003 206-063-632-001 206-063-632-003
<b>206L-1, 206L-3</b>	ALL	MAIN AUX AUX	206-064-611-001 206-063-632-005 206-063-632-007	
<b>212</b>	ALL	LH REAR RH REAR CENTER LH FLOOR RH FLOOR	205-060-605-011 205-060-605-013 205-060-605-005 212-060-600-3E 212-060-600-3G	FCE53917 FCE46052

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>214</b>	ALL	LH FORWARD RH FORWARD LH UPPER RH UPPER CENTER	205-062-635-001 205-062-635-002 205-062-635-015 205-062-635-017 205-062-635-013	
<b>222</b>	ALL	LH CENTER RH CENTER LH OUTBOARD RH OUTBOARD CENTER	222-366-678-101 222-366-678-102 222-366-679-101 222-366-679-102 222-366-677-101	
<b>412</b>	ALL	LH RH LH FLOOR RH FLOOR CENTER	412-060-603-101 412-060-603-102 412-060-601-101 412-060-601-102 412-060-602-101	

## **BOLKOW**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>BO-105C, CS CBS, LS</b>	ALL	#1 POSITION #2 POSITION #3 POSITION #1 SPLIT	FT/AO-17520 FT/AO-17521 FT/AO-17522 FT/AO-17523	

## **CESSNA**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>180</b>	30000-32661 30000-32661 32662-51063 32662-51063 51064-UP 51064-UP 51064-UP 51064-UP	LH MAIN RH MAIN LH MAIN RH MAIN LH MAIN RH MAIN LH MAIN EXT RANGE RH MAIN EXT RANGE	0726000-13 0726000-2 0726001-9 0726001-10 0726001-15 0726001-16 1200065-3 1200065-4	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>182</b>	33000-33842	LH MAIN	0726000-13	
	33000-33842	RH MAIN	0726000-2	
	33843-53598	LH MAIN	0726001-9	
	33843-53598	RH MAIN	0726001-10	
	53599-UP	LH MAIN	0726001-17	
	53599-UP	RH MAIN	0726001-18	
	53599-56143	LH MAIN EXT RANGE	1200065-5	
	53599-56143	RH MAIN EXT RANGE	1200065-6	
	56144-UP	LH MAIN EXT RANGE	1200065-23	
	56144-UP	RH MAIN EXT RANGE	1200065-24	
<b>185</b>	ALL	LH MAIN	0726001-15	
		RH MAIN	0726001-16	
		LH MAIN EXT RANGE	1200065-3	
		RH MAIN EXT RANGE	1200065-4	
<b>188</b>	ALL	LH MAIN	0726001-17	
		RH MAIN	0726001-24	
<b>190, 195</b>	ALL	LH MAIN	0322539	
		RH MAIN	0322539-1	
<b>205, 205A</b>	1-555	LH MAIN	0726001-19	
	1-555	RH MAIN	0726001-20	
	556-UP	LH MAIN	0726001-21	
	556-UP	RH MAIN	0726001-22	
	1-555	LH MAIN EXT RANGE	1200065-9	
	1-555	RH MAIN EXT RANGE	1200065-10	
	556-UP	LH MAIN EXT RANGE	1200065-13	
	556-UP	RH MAIN EXT RANGE	1200065-12	
<b>206, U206, P206</b>	1-137	LH MAIN	0726001-19	
	1-137	RH MAIN	0726001-20	
	138-UP/P206-ALL	LH MAIN	0726001-21	
	138-UP/P206-ALL	RH MAIN	0726100-22	
	1-137	LH MAIN EXT RANGE	1200065-9	
	1-137	RH MAIN EXT RANGE	1200065-10	
	138-UP/P206-ALL	LH MAIN EXT RANGE	1200065-13	
	138-UP/P206-ALL	RH MAIN EXT RANGE	1200065-12	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>	
<b>207, T207</b>	001-562	LH MAIN	0726001-21		
	001-562	RH MAIN	0726001-22		
	0563-UP	LH MAIN	0726001-25		
	0563-UP	RH MAIN	0726001-26		
	001-562	LH MAIN EXT RANGE	1200065-13		
	001-562	RH MAIN EXT RANGE	1200065-12		
	0563-UP	LH MAIN EXT RANGE	1200065-25		
	0563-UP	RH MAIN EXT RANGE	1200065-26		
	<b>210, T210</b>	57001-57840	LH MAIN	0726001-9	
57001-57840		RH MAIN	0726001-12		
57841-58351		LH MAIN	0726001-19		
57841-58351		RH MAIN	0726001-20		
58352-UP, T210		LH MAIN	0726001-21		
58352-UP, T210		RH MAIN	0726001-22		
57001-57840		LH MAIN EXT RANGE	1200065-10		
57001-57840		RH MAIN EXT RANGE	1200065-23		
57841-58351		LH MAIN EXT RANGE	1200065-9		
57841-58351		RH MAIN EXT RANGE	1200065-10		
58352-UP, T210		LH MAIN EXT RANGE	1200065-13		
58352-UP, T210		RH MAIN EXT RANGE	1200065-12		
<b>310, 310 TURBO</b> <i>(40 GALLON SYSTEM USES ONE TANK PER SIDE. 63 GALLON SYSTEM USES TWO TANKS PER SIDE)</i>		ALL TO K245	LH	0823343-5	
		ALL TO K245	RH	0823343-6	
	L0001-Q1069	LH 40 GALLON SYSTEM	0823362-1		
	L0001-Q1069	RH 40 GALLON SYSTEM	0823362-2		
	Q1070-UP	LH 40 GALLON SYSTEM	0823362-5		
	Q1070-UP	RH 40 GALLON SYSTEM	0823362-6		
	Q0601-UP	LH 63 GALLON SYSTEM	0823362-3, INBOARD		
	Q0601-UP	RH 63 GALLON SYSTEM	0823362-4, INBOARD		
	Q0601-UP	LH 63 GALLON SYSTEM	5026102-3, OUTBOARD		
	Q0601-UP	RH 63 GALLON SYSTEM	5026102-4, OUTBOARD		
	35000-35441	LH-RH TIP	0823100-1		
	35442-39132	LH-RH TIP	082300-11		
	35154-UP	LH-RH TIP ALT	0823110-3		
	P0001-UP	LH LOCKER	9910023-3		
	P0001-UP	RH LOCKER	9910023-4		
		LH LOCKER	9910304-1		
		RH LOCKER	9910304-2		
<b>320</b>	0001-E0037	LH 40 GALLON SYSTEM	0823362-5		
	0001-E0037	RH 40 GALLON SYSTEM	0823362-6		
	E0038-UP	LH 40 GALLON SYSTEM	0823362-1		
	E0038-UP	RH 40 GALLON SYSTEM	0823362-2		
	ALL	LH-RH TIP	0823100-11		

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>335</b>	ALL	LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM	0823362-3, INBOARD 0823362-4, INBOARD 5026102-3, OUTBOARD 5026102-4, OUTBOARD	
<b>340, 340A</b>  <i>(40 GALLON SYSTEM USES ONE TANK PER SIDE. 63 GALLON SYSTEM USES TWO TANKS PER SIDE)</i>	001-0331 001-0331 0332-UP 0332-UP  ALL	LH 40 GALLON SYSTEM RH 40 GALLON SYSTEM LH 40 GALLON SYSTEM RH 40 GALLON SYSTEM LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM LH LOCKER RH LOCKER LH LOCKER RH LOCKER	0823362-1 0823362-2 0823362-5 0823362-6 0823362-3, INBOARD 0823362-4, INBOARD 5026102-3, OUTBOARD 5026102-4, OUTBOARD 9910023-3 9910023-4 9910304-1 9910304-2	
<b>401, 401A, 401B 402, 402A, 402B</b>  <i>(40 GALLON SYSTEM USES ONE TANK PER SIDE. 63 GALLON SYSTEM USES TWO TANKS PER SIDE)</i>	0001-B0589 0001-B0589 B0590-UP B0590-UP B0590-UP B0590-UP B0590-UP B0590-UP B0590-UP 001-B1200 001-B1200 B1201-UP B1201-UP	LH 40 GALLON SYSTEM RH 40 GALLON SYSTEM LH 40 GALLON SYSTEM RH 40 GALLON SYSTEM LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM LH 63 GALLON SYSTEM RH 63 GALLON SYSTEM LH LOCKER RH LOCKER LH LOCKER RH LOCKER	0823362-1 AUX 0823362-2 AUX 0823362-5 AUX 0823362-6 AUX 0823362-3, INBOARD 0823362-4, INBOARD 5026102-3, OUTBOARD 5026102-4, OUTBOARD 9910023-3 9910023-4 9910304-1 9910304-2	
<b>411, 411A</b>	ALL	LH INBOARD RH INBOARD LH OUTBOARD (CENTER) RH OUTBOARD (CENTER) LH AUX RH AUX LH LOCKER RH LOCKER	5026002-7, -5 5026002-8, -6 5026002-9, -3 5026002-10, -4 5026102-3, -1 5026102-4, -2 9910027-1 9910027-2	

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>414, 414A</b> (40 GALLON SYSTEM USES ONE TANK PER SIDE. 63 GALLON SYSTEM USES TWO TANKS PER SIDE)	0001-0511	LH 40 GALLON SYSTEM	0823362-1 AUX	
	0001-0511	RH 40 GALLON SYSTEM	0823362-2 AUX	
	0512-A0001	LH 40 GALLON SYSTEM	0823362-5 AUX	
	0512-A0001	RH 40 GALLON SYSTEM	0823362-6 AUX	
	ALL	LH 63 GALLON SYSTEM	0823362-3 INBOARD	
		RH 63 GALLON SYSTEM	0823362-4 INBOARD	
		LH 63 GALLON SYSTEM	5026102-3 OUTBOARD	
		RH 63 GALLON SYSTEM	5026102-4 OUTBOARD	
		LH LOCKER	9910023-3	
		RH LOCKER	9910023-4	
	<b>421, 421A, 421B, 421C</b>	ALL	LH INBOARD	5026002-7, -5
		RH INBOARD	5026002-8, -6	
		LH OUTBOARD (CENTER)	5026002-9, -3	
		RH OUTBOARD (CENTER)	5026002-10, -4	
		LH AUX	5026102-3, -1	
		RH AUX	5026102-4, -2	
ALL TO C200		LH LOCKER	9910027-1	
ALL TO C200		RH LOCKER	9910027-2	
C201-UP		LH LOCKER	9910241-3, -1	
C201-UP		RH LOCKER	9910241-4, -2	



**DEHAVILLAND**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>DHC-1 CHIPMUNK</b>		LEFT HAND RIGHT HAND LEFT HAND RIGHT HAND LEFT HAND RIGHT HAND	1920 1930 AM1223-S (RAISED NECK) AM1223-P (RAISED NECK) AM1262-S AM1262-P	
<b>DHC-2 BEAVER</b>	ALL	FRONT CENTER REAR	C2PT431A C2PT433A C2PT435A	FCD60530 FCD60531 FCD60532
<b>DHCT-2 TURBO BEAVER</b>	ALL	FRONT CENTER FRONT CENTER REAR REAR (FWD OF ALL OTHER FUEL CELLS)	C2PT431A C2PT433A C2PT435A FCD-60965	FCD60530 FCD60531 FCD60532
<b>DHC- 3 OTTER</b>	ALL	FRONT CENTER FRONT CENTER REAR REAR	P/N C3PT31-5 P/N C3PT32-5 P/N C3PT33-5 P/N C3PT34-5	FCD60125 FCD60126 FCD60127 FCD60128
<b>DHC-4 CARIBOU</b>	ALL	# 1 LEFT HAND # 1 RIGHT HAND # 2 LEFT HAND # 2 RIGHT HAND # 3 LEFT HAND # 3 RIGHT HAND # 4 LEFT HAND # 4 RIGHT HAND # 5 LEFT HAND # 5 RIGHT HAND # 6 LEFT HAND # 6 RIGHT HAND # 7 LEFT HAND # 7 RIGHT HAND	C4SC1071-3 C4SC1071-4 C4SC1072-3 C4SC1072-4 C4SC1073-3 C4SC1073-4 C4SC1074-3 C4SC1074-4 C4SC1075-3 C4SC1075-4 C4P1136-23 C4P1136-24 C4P1137-23 C4P1137-24	
<b>DHC-6 TWIN OTTER</b>	ALL	NUMBER 1 NUMBER 2 NUMBER 3 NUMBER 4 NUMBER 5 NUMBER 6 NUMBER 7 NUMBER 8	C6SC1051-3 C6SC1052-3 C6SC1053-3 C6SC1054-3 C6SC1055-3 C6SC1056-3 C6SC1057-3 C6SC1058-3	

**HELIO**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>COURIER</b>	ALL	LH MAIN	391-080-400-10	
		RH MAIN	391-080-400-11	
	H295 ONLY	LH AUX	391-080-400-10	
	H295 ONLY	RH AUX	391-080-400-11	

**HILLER**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>UH-12 FH 1100</b>	ALL	MAIN	2T6C2043-1	
	ALL	MAIN	24-72074-1	

**HUGHES**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>500C &amp; D</b>	ALL	LH	369H8101-3	369H8101-3A, (369H8101-3-A) 369H8101-5A, (369H8101-5-A)
		RH	369H8101-5	

**LUSCOMBE**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>SILVAIRE</b>	ALL	LH	086114-0	
		RH	086114-1	

**LEARJET**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>23</b>	3-047	LH	6600028-003	
	3-047	RH	6600028-004	
	48-UP	LH	6600080-005	
	48-UP	RH	6600080-006	
<b>24</b>	1-139	LH	6600080-005	
	1-139	RH	6600080-006	
	140-UP	LH	6600099-003	
	140-UP	RH	6600099-004	
<b>25</b>	ALL	LH	6600140-001	
	ALL	RH	6600140-002	
	E25C & F	LH	6600160-001	
	E25C & F	RH	6600160-002	
<b>28</b>	ALL	LH	6600250-3	
		RH	6600250-4	
		LH	6600254-1	
		RH	6600254-2	
<b>31</b>	ALL	LH FUSELAGE	6600316-15	
		RH FUSELAGE	6600316-16	
<b>35, 35A (C21A)</b>	ALL	LH FUSELAGE	6600316-5	
		RH FUSELAGE	6600316-6	
		LH FUSELAGE	6600316-13	
		RH FUSELAGE	6600316-14	
<b>36</b>	ALL	LH	6600160-1	
		RH	6600160-2	
		LH	6600160-5	
		RH	6600160-6	
<b>55</b>	ALL	MAIN FUSELAGE	6600467-8	
	EXT. RANGE	AFT FUSELAGE	6600443-13	

**PIPER**

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>PA23-150, -160, -235, APACHE</b>	ALL	LH MAIN AND AUX 36 GALLON RH MAIN AND AUX 36 GALLON 18 GALLON LH AUX 18 GALLON RH AUX	454-320 454-321 454-322 454-323	
<b>PA23-250 AZTEC</b>	ALL TO 7405476 ALL TO 7405476 7554001-UP 7554001-UP 7554001-7554168 7554001-7554168 7654001-UP 7654001-UP 7654001-UP 7654001-UP	LH MAIN & AUX RH MAIN & AUX LH MAIN RH MAIN LH AUX RH AUX LH AUX RH AUX LH TIP RH TIP	454-320 454-321 454-365 454-366 454-365 454-366 454-367 454-368 454-369 454-370	33605-00 33605-01 33605-00 33605-01 33779-02 33779-03 33848-02 33848-03
<b>PA24-180 COMANCHE</b>	ALL	LH MAIN RH MAIN	454-324 454-325	20355-00 20355-01
<b>PA24-250 COMANCHE</b>	1-2843 1-2843 2844-UP 2844-UP 2844-UP 2844-UP	LH MAIN RH MAIN LH MAIN RH MAIN LH AUX RH AUX	454-324 454-325 454-334 454-335 454-326 454-327	20355-00 20355-01 23799-00 23799-01 22037-00 22037-01
<b>PA24-260 COMANCHE</b>	3558-UP 3558-UP ALL ALL	LH MAIN RH MAIN LH AUX RH AUX	454-334 454-335 454-326 454-327	23799-00 23799-01 22037-00 22037-01
<b>PA24-400 COMANCHE</b>	ALL	LH MAIN RH MAIN LH AUX RH AUX	454-334 454-335 454-328 454-329	23799-00 23799-01 22703-00 22703-01
<b>PA25 PAWNEE</b>	ALL	MAIN	64954-00	65954-1
<b>PA30, PA39 TWIN COMANCHE</b>	ALL	LH MAIN RH MAIN LH AUX RH AUX	454-334 454-335 454-332 454-333	23799-00 23799-01 22037-02 22037-03

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>PA36 BRAVE</b>	ALL	LH RH	97990-02 97990-03	
<b>PA31-300, -310, -325 NAVAJO</b>	7300923 5-7300923 7300924-UP 7300924-UP ALL ALL	LH MAIN RH MAIN LH MAIN RH MAIN LH AUX RH AUX	71089-04, -2 71089-05, -3 71028-04, -2, 71028-05, -3, 71027-04, -2 71027-05, -3	(461-725) (461-726) 52778-00, (461-713) 52778-01, (461-712) 40519-00, (461-714) 40519-01, (461-715)
<b>PA31P NAVAJO</b>	3-115 3-115 116-UP 116-UP ALL	LH MAIN RH MAIN LH MAIN RH MAIN LH AUX RH AUX LH NACELLE RH NACELLE	40518-04, -2 40518-05, -3 52778-12, -2 52778-13, -3 40519-04, -2 40519-05, -3 45919-02, 45919 45919-03, -01	461-729 461-730 461-727 461-728 461-717 461-716 461-718 461-719
<b>PA31P-350 MOJAVE</b>	ALL	LH MAIN RH MAIN LH AUX RH AUX LH NACELLE RH NACELLE	52778-16, -8 52778-17, -9 82127-04, -2 82127-05, -3 82139-06, -2 82139-07, -3	454-410 454-411 454-414 454-415 454-412 454-413

<i>MODEL</i>	<i>ELIGIBILITY</i>	<i>DESCRIPTION</i>	<i>O.E.M. P/N</i>	<i>Alternate</i>
<b>PA31T, T1, T2 CHEYENNE</b>	ALL	LH MAIN RH MAIN LH AUX RH AUX	52778-14, -6 52778-15, -7 50219-04, -2 50219-05, -3	461-722 461-723 461-720 461-721
<b>PA32 SARATOGA</b>	ALL	LH RH	461-710 461-711	2F1-4-44197-7 2F1-4-44197-8
<b>PA34-200T, -220T SENECA</b>	7670114-UP	CENTER WING	41832-3,	2F1-6-41832-3
<b>PA42 CHEYENNE III</b>	ALL	LH MAIN INBOARD RH MAIN INBOARD LH FORWARD OUTBOARD RH FORWARD OUTBOARD LH AFT INBOARD RH AFT OUTBOARD	56033-06, -4 56033-07, -5 56031-06, -4 56031-07, -5 56032-06, -4 56032-07, -5	461-703 461-704 461-701 461-702 461-699 461-700
<b>PA42-1000 CHEYENNE 400LS</b>	ALL	LH MAIN INBOARD RH MAIN INBOARD LH AFT INBOARD RH AFT INBOARD	75415-4 75415-5 75388-4 75388-5	461-735 461-734 461-733 461-732
<b>PA44-180, -180T SEMI NOLE</b>	ALL	LH RH	86243-2 86243-3	461-697 461-698